



1. Carefully remove the hardware from packaging inside Storage Compartment.

2. Place open Storage Compartment onto scooter rear mounting rack, with taillight facing toward rear of vehicle.

3. Confirm that the bolt holes aligned over large gaps between rack crossbars.

4. Insert washers over 8mm bolt fasteners.

5. Insert 10mm bolts through the top of the mounting holes on the inside of the compartment.

6. Place mounting brackets onto underside of mounting rack with bolts inserted into holes.

7. Place fastening nuts (with thread locking compound) over bolts and tighten.

8. Tighten nut fasteners using ratchet wrench with 10mm socket and 10mm hand wrench to counter-stabilize bolts for tighter mounting.

